Shutter / Door Alarm - PDAS Series



Keep your shop / home secured!

MAIN FEATURES :

- This alarm system can be installed on a shutter or a door and it gives out a loud siren on intrusion.
- ◆ Highly reliable key-enabled micro-controller system for single door or shutter.
- On entering if the alarm is not disabled within 15 seconds, it gives out a loud siren, indicating intrusion.
- ✤ Piezo electric buzzer of approx 85 dB gives loud sound output on intrusion.
- + Unlock your door with just a touch on the indoor screen. Fully secure and compatible electric locks are also provided.
- ◆ Operates on AA cells, 4 nos. (Supplied with the machine). Requires no electric connection.
- Long battery life of about 8 months.
- Compatible with all PHOENIX door entry systems.
- Dimensions : 200(L) x 78(W) x 46(H) mm

APPLICATIONS : + Shops + Homes + Offices.

NITIRAJ ENGINEERS LTD.

CIN: L31909MH1999PLC119231

Corp. Office : J-25, J-26, M.I.D.C., Awdhan, DHULE - 424006 (M.S.) INDIA. Tel. : +91-2562-295181, 295281

E-mail: response@nitiraj.net

Specifications are subject to change without piror notice.