



Keep your shop and warehouse secured!

MAIN FEATURES :

- ◆ This alarm system can be installed on a shutter and gives out a loud siren (120 dB) and also sends SMS and calls to 5 registered mobile numbers, on intrusion.
- ◆ User needs to insert a SIM card for using SMS and calling feature.
- ◆ On entering, if the system is not disabled within a particular time, it gives out the siren.
- ◆ The system can be disabled using its key, or by the registered mobile numbers.
- ◆ User can also set the day and time period for the alarm system to be enabled regularly, by SMS.
- ◆ Other SMS setting include registering mobile numbers, checking the battery, checking the SIM network range, enabling or disabling the alarm, etc
- ◆ Adjustable delay before siren : You can set the number of seconds after which the siren should start ringing, once the shutter is opened. The default value is 10 seconds.
- ◆ This system works on 2 batteries – pencil cells x 4 and a Li-ion rechargeable battery. It requires no electric connection.
- ◆ Battery charging wire is provided with the system and a battery life of approximately 1 week is expected for rechargeable battery. The pencil cells can give a battery life of about 6 months.
- ◆ This system is easy to install as it has a spring rod-type sensor. Installation process is simple with only the alarm body to be fit on the shutter using 4 nut-bolts.
- ◆ Alarm body is made up of metal and it is sturdy and secure.

APPLICATIONS :

- ◆ Shops, storage godowns, warehouses.
- ◆ Offices.
- ◆ Banks, ATMs.

DIMENSIONS :

- ◆ Alarm system : 200(L) x 78(W) x 46(H) mm

